

# Tensorgrip®



# F26

## DCM FREE UPHOLSTERY ADHESIVE


TensorGrip® F26 is a DCM FREE adhesive with exposure reduction benefits for users, along with a highly controllable spray pattern. This web spray contact adhesive has been developed for general foam, fabric and upholstery applications.

### ADVANTAGES

- DCM FREE Adhesive.
- Highly Controllable Spray Pattern.
- High Green Strength.
- Temperature Resistant Up to 80°C.

### TECH DATA

#### SQUARE METRE COVERAGE (m<sup>2</sup>)\*:




#### APPLICATION:



#### OPEN TIME\*\*:



#### SUITABLE FOR:



#### FLASH-OFF\*:



#### COLOUR:



#### PROPERTIES:



\*consult the Spray Manual for a more detailed tutorial on the bonding process.  
\*\*depending on ambient temperature.

CHEMICAL TECHNICAL DATA

Viscosity	350 cps 25°C sp#2, 30r.p.m.
Total Solids	26%
Colour	Clear
System Flammability	Flammable adhesive in a flammable propellant
Shear	456N
Peel	Not available
Shear Adhesion Failure Temp (SAFT) 100grams	80 °C
Flash-Off	1 - 2 minutes depending on temperature and humidity
Open time	Up to 20 mins
Shelf Life	18 months from date of manufacture

HANDLING & STORAGE

- Consult Safety Data Sheet prior to use.
- DO NOT expose to temperatures exceeding 50°C/122°F.
- Store at temperatures between 10°C and 25°C.
- Avoid exposing aerosol containers to high temperatures or direct sunlight.
- Keep away from heat, hot surfaces, sparks, open flames, and other ignition sources.
- Shake well before use.
- To prevent nozzle from blocking, turn can upside down, press nozzle until spray is clear of adhesive.
- Replace cap after use to protect actuator / valve.
- Use only in a well ventilated area.
- Always test product to determine suitability for your particular application prior to use in production.

DIRECTIONS FOR USE

- This product is designed to be applied to two surfaces to be bonded together. For best results, the temperature of the adhesive and the surfaces being bonded should be between 60 °F - 80 °F (16 °C - 27 °C).
- Use with adequate ventilation.
- Prior to use, check compatibility by spraying a small test patch of the adhesive on the substrate. This product may degrade some substrates.



1. SHAKE WELL BEFORE USE.



2. Make sure that surfaces are clean, dry and free from dirt, dust, oil, loose paint, wax or grease, etc.



3. Spray about 10-20 cm (4" – 8") away at a 90° angle to the surface, applying a uniform, even coat of adhesive to obtain 80% to 100% coverage of the surface.



4. If necessary, spray another coat of adhesive in areas that appear to need more adhesive. Spray surfaces vertically and horizontally.



5. Allow 1 - 2 minutes for adhesive to tack off until no adhesive transfers to the knuckle when touched.




6. Adhere surfaces and press together with adequate pressure. Allow 24 hours for the adhesive to fully cure.

7. To prevent nozzle from blocking, turn can upside down press nozzle until spray is clear of adhesive. If nozzle becomes blocked, the adhesive can be removed with a solvent such as lacquer thinner or acetone.

COVERAGE



COVERAGE TOO LIGHT



COVERAGE TOO HEAVY



CORRECT APPLICATION = 20 dry gms/sqm